

BEDSIDE GUN FU295300

EN

## RF28206

DIMMER LED 1004P LFP100-240V 4-150WHL 4-25W



Bedside  
Gun  
p.12



Chiara T  
p.03



Glo-ball  
Basic 0  
p.11



Glo-ball  
Basic 1  
p.14



Glo-ball  
Basic 2  
p.05



Glo-ball  
T1  
p.11



Ic T1  
High  
p.08



Ic T1  
Low  
p.08



Ic T2  
p.08



Ktribe T1  
p.05



Ktribe T2  
p.05



Miss  
K  
p.13



Ray T  
p.17



Romeo  
Moon  
T1  
p.32



Romeo  
Soft T1  
p.32



Spun  
Light  
T1  
p.12



Spun  
Light  
T2  
p.12



Table  
Gun  
p.12

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

**BEDSIDE GUN** FU295300

**EN**

## RF28206

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W



Fig.1




Fig.2

Open the dimmer box of the damaged dimmer.  
For the opening, it is necessary to remove the n°2 screws using a star screw driver.

Lift-up the dimmer casing from the dimmer base;

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - [www.flos.com](http://www.flos.com)  
Flos reserves the right to introduce any changes to its own models, without prior notice.

BEDSIDE GUN FU295300

EN

## RF28206

LED DIMMER 1004P LFP100-240V 4-150WHL 4-25W




Fig.3




Fig.3.1

Remove the cable clamps by unfastening the 4 screws (A) and disconnect the wires from the terminal blocks through a tiny flat headed screw driver;



Fig.4

Replace the dimmer and connect the wires. When connecting the wires it is necessary to respect the polarities (L = Brown and N = Blue) to the terminal box. Lock the electrical cables by fastening the screws (A) of the cable clamps and make sure to block the isolation of the electrical cable.

Close the dimmer box. It is necessary to place the casing on top and press down until it locks in. it is necessary to insert the n°2 screws using a star screw driver

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.