


FU952034

Wireline



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

FU952034

Wireline



Fig.1



Fig.2

Unfasten the screw (A) using the allen key and disassemble the ceiling rose.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

FU952034

Wireline



Fig.3



Fig.4

Unfasten the screw (B) using the allen key and lift the cover.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

FU952034

Wireline



Fig.5




Fig.6

Disconnect the dimmer cables.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

FU952034

Wireline



Fig.7



Fig.8

Remove the dimmer from the metal base.
Assemble now the new spare-part.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.