

RF09514


Ring nut assembly for diffuser 2



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF09514

Ring nut assembly for diffuser 2



Insert the ring nut (A) in the glass diffuser hole and then fasten the screws (B).
REMARKS!!! Do not tighten the screws hard. Risk cracking the glass diffuser.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.