ΕN

## F0418030

Arrangements Recessed Rose



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ΕN

## F0418030

Arrangements Recessed Rose




Fig.1

01. RF0410400 –Stretch cable ceiling rose kit
02. RF0410300 –Led dimmer kit
03. RF27614 – Recessed power unit
04. RF27613 – Recessed ceiling wall assembly
06. RF26773 –Recessed ceiling wall cover
09. 26602 – Spacers cable
10. RF26440 – Regolation cables key
11. RF26906 –Element support assembly

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.