

## RF6608100

Taccia Led Jack plug with cable and push dimmer



## RF6608100

Taccia Led Jack plug with cable and push dimmer






Fig.1 Fig.2

Unfasten the 2 screws (A) from underneath the dimmer and remove the dimmer cover (B).

## RF6608100

Taccia Led Jack plug with cable and push dimmer






Fig.3 Fig.4

Unfasten the 2 screws (C) of the cable clamp (D) and disconnect the wires from the terminal box (F) through a tiny flat headed screw driver.

3



## RF6608100

Taccia Led Jack plug with cable and push dimmer




Fig.5 Fig.6

Connect the electrical wires to the terminal (F) respecting the polarities of the dimmer.

Position the cable clamp (D) and fasten back the screws (C).

Close the dimmer by positioning the cover (B) and fastening the 2 screws (A)