

ΕN

RF30216

Bellhop Floor Switch Dimmer Assembly 700mA



ΕN

RF30216

Bellhop Floor Switch Dimmer Assembly 700mA




Fig.1

Connect the plug (A) to the push button switch (B) locking it by turning it 90° clockwise.

ΕN

RF30216

Bellhop Floor Switch Dimmer Assembly 700mA




Fig.2

Connect the plug (C) to the power unit (D) locking it in by rotating it 90° clockwise.