


F0418030

Arrangements Recessed Rose



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

F0418030

Arrangements Recessed Rose




Fig.1

- 01. RF0410400 –Stretch cable ceiling rose kit
- 02. RF0410300 –Led dimmer kit
- 03. RF27614 – Recessed power unit
- 04. RF27613 – Recessed ceiling wall assembly
- 06. RF26773 –Recessed ceiling wall cover
- 09. 26602 – Spacers cable
- 10. RF26440 – Regulation cables key
- 11. RF26906 –Element support assembly

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.