

RF26382

#ASS.SWT DIMM.400MA MAX(ENTITY)



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF26382

#ASS.SWT DIMM.400MA MAX(ENTITY)




Fig.1

Connect the plug (P) to the push button switch (Q) locking it by turning it 90° clockwise.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF26382

#ASS.SWT DIMM.400MA MAX(ENTITY)




Fig.1

Connect the plug (C) to the power unit (B) locking it in by rotating it 90° clockwise.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.