

RF04607

Electrical wiring from transformer to bulb



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF04607

Electrical wiring from transformer to bulb




Fig.1

Insert the connector (D) inside the fitting of the lamp-bulb (C).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF04607

Electrical wiring from transformer to bulb




Fig.2

Pass the electrical cable through the cable loops (E).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF04607

Electrical wiring from transformer to bulb




Fig.3

Connect the plug (F) to the socket (G) of the transformer.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF04607

Electrical wiring from transformer to bulb




Fig.4

Wrap the excess cable around the cable winding support (H).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.