


**RF0303200**

Arco Led Optical led diffuser with fixing screws



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.

**RF0303200**

Arco Led Optical led diffuser with fixing screws




Fig.1

Lift the reflector (L) from the grid (M) by sliding it along the channel (H) and the stem (B) and lean it on the top of the marble base (F) of the appliance.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

**RF0303200**

Arco Led Optical led diffuser with fixing screws




Fig.2

Unscrew the four fixing screws (R) and remove then the damaged diffuser (S) from its housing.  
**WARNING!** Be careful not to lose the four screws because they are special screws with limited availability.

Assemble now the new spare-part:

Install the diffuser (S) by fastening the four screws (R).

Place the reflector (L) on the grid (M). (Fig.1 page 56)

**WARNING!** When installing and whenever acting on the appliance, ensure that the power supply has been switched off.  
For the installation of the spare-part, it is necessary to consult a qualified electrician.