

ΕN

F3692056A

POLISHED INOX TOP COVER







Last Order Fluted

ΕN

LAST ORDER CLEAR F3693056

F3692056A

POLISHED INOX TOP COVER




Fig.1

Remove the top-cover (A) from the led body (B).

Assemble now the new spare part.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

ΕN

LAST ORDER FLUTED F3694056

F3692056A

POLISHED INOX TOP COVER




Fig.1

Remove the top-cover (A) from the led body (B).
Assemble now the new spare part.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.