

ΕN

RF6255008

fabric diffuser assembly



ΕN

RF6255008

fabric diffuser assembly




Fig.1

Lock the external diffuser (A) to the inner diffuser (B) by forcing (pushing) it to clicks-on. To lock the Soft version diffusers, it is necessary to locate the diffuser (A) on top of the inner diffuser (B) and force it harder in way that it clips-on to the diffuser (B).