EN

RF6410147

Rust ceiling rose assembly

RF6410147

Rust ceiling rose assembly

Fig.1

Fix the wall fixture (A) with the appropriate expansion bolts. NOTE: Select and employ screw anchors which are suited to the surface where the appliance is to be installed.
Connect the power cable to the terminal box (not supplied with the spare-part). Mount the ceiling-rose (F).