

RF28209

BLACK LED ARDITI DIMMER 4W-25W



Bibliotheque
Nationale



Glo-ball
F1



Glo-ball
F2



Glo-ball
F3



Ic F1



Ic F2




Ktribe
F2



Ktribe
F3



Lounge
Gun



Luminator
Dim



Parentesi D



Parentesi
50



Ray
F1



Ray F2



Romeo
Moon F



Romeo
Soft



Spun
Light F



Toio
Led

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF28209

BLACK LED ARDITI DIMMER 4W-25W



Fig.1

Open the box of the damaged dimmer.

Unfasten the 2 fixing screws.



Fig.2

Turn the box and remove the terminal cover.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF28209

BLACK LED ARDITI DIMMER 4W-25W



Fig.3

Unfasten the screw from cable clamp.



Fig.4

Remove the cable clamp and disconnect the wires from the green terminal box.

Assemble now the new spare part. Connect the conductors respecting the polarities, lock the cables by positioning the cable clamp and then fasten the screw, cover the green terminal box with the cover, turn the dimmer box and fasten back the two screws.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.