

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly




Fig.1



Fig.2

Remove the joint (A) by unfastening it with a pair of pliers (B).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.3




Fig.4

Lift-up the varnished body (C) from the internal body (D).
Unscrew the screw (E).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.5



Fig.6

Disconnect the cables from the clamps (F).
Loosen the electrical cable from the sink.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.7



Fig.8

Unscrew the 4 screws (G) from the white reflector.
Remove the diffuser.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.9



Fig.10

Screw the 4 screws (G) to the white reflector.

NOTE!

Do not screw so fast!!!

Insert the electrical cable in the sink.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

©2021 Flos - All rights reserved - www.flos.com
Flos reserves the right to introduce any changes to its own models, without prior notice.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.11




Fig.12

Connect the cables to the new clamps (H).

NOTE!

Respect the polarity of the cables.

Screw the screw to fix the electrical cable.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF0095600

Aim Small Heatsink, 2700K Led Module & Reflector Assembly



Fig.13



Fig.14

Insert the new internal body (D) in the varnished body (C).
Re-assemble the Joint (A).
Screw the joint (A) with a pair of pliers (B).(Fig.1 page 13).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.