


RF0410300

Led dimmer kit



RF0410300

Led dimmer kit





Fig.1 Fig.2

Remove the cover.



RF0410300

Led dimmer kit





Fig.3 Fig.4

Unscrew the screws (A) from the old dimmer using a screwdriver.

Disconnect the wires from the old dimmer.



RF0410300

Led dimmer kit





Fig.5 Fig.6

Unscrew the screws (B) from the old dimmer using a screwdriver. Disconnect the wires of the push dimm from the old dimmer.



RF0410300

Led dimmer kit





Fig.7 Fig.8

Unscrew the screws (C) from the old dimmer using a screwdriver. Remove the old dimmer from the ceiling rose.



RF0410300

Led dimmer kit





Fig.9 Fig.10

Position the new dimmer in the ceiling rose. Fasten back the screws (C) of the new dimmer using a screwdriver.

RF0410300

Led dimmer kit






Fig.11 Fig.12

Connect the wires to the new dimmer.

Fasten the screws (A & B) of the new dimmer using a screwdriver.

Place the cover on the ceiling rose.



RF0410300

Led dimmer kit





Fig.1 Fig.2

Remove the top plate using a screwdriver.

RF0410300

Led dimmer kit





Fig.3 Fig.4

Remove the black plate using an allen key.

RF0410300

Led dimmer kit





Fig.5 Fig.6

Disconnect the power supply.



RF0410300

Led dimmer kit





Fig.7 Fig.8

Remove the cover from the internal body.



RF0410300

Led dimmer kit





Fig.9 Fig.10

Disconnect the push bottom from the old dimmer. Unscrew the screws that fix the dimmer to the black plastic support.

RF0410300

Led dimmer kit





Fig.11 Fig.12

Remove the old dimmer.

ASSEMBLE NOW THE NEW SPARE PART:

Position the new dimmer and connect the cables.

Fasten back the screws.

Position the cover on the internal body.

Position and fix the black plate using the allen key.

Connect the plate on the top of the ceiling rose.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.