

2097/50 A1502057

ΕN

RL7060657

CHROME LONG ARM (475mm)






2097/50 A1502057

ΕN

RL7060657

CHROME LONG ARM (475mm)



Screw the arms (H) to the lamp body (I), taking care not to bend on the rings (L). Insert the lamp holder (M) in the ring (L) and fasten them by locking the screw (N).

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off. For the installation of the spare-part, it is necessary to consult a qualified electrician.