

RF04727

Biagio White Electrical Wiring EU



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF04727

Biagio White Electrical Wiring EU




Fig.1




Fig.2

Separate the ring nut (A) from the light bulb holder (B) by unscrewing it.
Insert the lamp holder (B) into the ring support (C) and lock it by tightening the ring nut (C); install the light bulb.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.