

RF23032


Ok White ceiling rose



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF23032

Ok White ceiling rose

**Fig.1**

Drill a hole in the ceiling and insert the expansion plug (A). Tighten and fasten the rose (B).
REMARKS! Select and employ screw plugs which are suited to the surface where the appliance is to be installed.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.