

ΕN

RF02784

Lamp holder support



ΕN

RF02784

Lamp holder support




Fig.1

Remove the anti dust screen (A) by bending the sides of the screen and removing it from the electrical cable.

ΕN

RF02784

Lamp holder support





Fig.2 Fig.3

Remove the lamp holder from its support and disconnect the electrical wires by pressing the push terminals with a paper clip (E) or something similar.

Collocate the electrical assembly (B) inside the internal glass diffuser (C), ensuring that the three lamp holder supports are hooked on the three openings (D) present on the glass diffuser (C). Insert the anti dust screen (A) by bending the sides of the screen and inserting it through the electrical cable. (Fig.1)