

RF02783


Lamp holder support



WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF02783

Lamp holder support

**Fig.1**

Remove the anti-dust screen (A) by bending the sides of the screen and removing it from the electrical cable.

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.

RF02783

Lamp holder support




Fig.2




Fig.3

Pull out the electrical assembly (B) from the appliance. Hook the three supports (C) to the lamp holder assembly (B).

Collocate the electrical assembly (B) inside the internal glass diffuser (C), ensuring that the three lamp holder supports are hooked on the three openings (D) present on the glass diffuser (C).
Insert the anti dust screen (A) by bending the sides of the screen and inserting it through the electrical cable.
(Fig.1)

WARNING! When installing and whenever acting on the appliance, ensure that the power supply has been switched off.
For the installation of the spare-part, it is necessary to consult a qualified electrician.